

## Enable Fax Function on Lexmark – Web Interface:

In the Web Interface, click on Links & Index

Device Status
Scan Profile
Copy Printer Settings
Settings
Reports
<b>Links &amp; Index</b>
Applications
Order Supplies

Select Security from the list

- SMTP Setup
- SNMP
- Scaling
- Schedule Power Saver
- Security**
- Select Active Network Card
- Set Date and Time
- Set SNMP Traps
- Setup Menu

Select Security Setup

- Security**
- Security Setup**
- Miscellaneous Security Settings
- Schedule USB Devices
- Confidential Print Setup

Select Access Controls

Step 3: Apply your Security Template to one or more **Access Controls.**

Scroll down until you see Fax Function. Select No Security from the drop-down box. Click Submit at the bottom when complete.

